INSTALLATION GUIDE

770M+ SERVO UPGRADE KIT





Page 1



1.1 PURPOSE

This document gives instructions on installing the 770M+ Servo Upgrade Kit on a mill.

1.2 PRODUCT INFORMATION

Product: 770M+ Servo Upgrade Kit (PN 39275)

Quantity	Description	
1	770M+ Enclosure Decal (PN 39395)	
1	770M+ Electrical Cabinet Decal (PN 39394)	
3	8-Position Terminal Block (PN 32877)	
4	Adapter Plate (PN 39362)	
4 ft	Butyl Tape (PN 34133)	
4	Cable Gland (PN 35974)	
1	Dielectric Grease (PN 38268)	
4	Flex Conduit Fitting (PN 30628)	
4	M5 × 0.8 - 20 mm Socket Cap Screw (PN 30357)	
4	M5 Flat Washer (39305)	
4	M5 Lock Washer (PN 30534)	
1	M5 Tap (PN 33420)	
1	M5 Tap Drill (PN 33641)	
3	Servo Control Cable (PN 39047)	

Quantity	Description
3	Servo Power Cable (PN 39046)
7	Spade Electrical Connector (PN 30610)
1	X-Axis Flex Conduit (PN 30627)
1	X-Axis Motor Cover Assembly (PN 39284)
1	X-Axis Servo Motor (PN 38406)
1	Y-Axis Servo Motor (PN 38702)
1	Z-Axis Brake (PN 38399)
1	Z-Axis Servo Motor (PN 38407)

Note: If any of these items are missing, we can help. Email <u>support@tormach.com</u> to contact Tormach Technical Support for guidance on how to proceed.

1.3 REQUIRED TOOLS

This procedure requires the following tools. Make sure that you have them available before you begin.

- 1-2-3 block (or similar)
- Ammonia-free window cleaner (or similar)
- Bar clamp
- Center punch
- Channellock pliers
- Electric drill
- Electrical tape (or similar)
- Flat-blade screwdriver
- Flat-blade screwdriver, small
- Ladder, about 3 ft
- Marker
- Metric hex wrench set
- Mild degreaser
- Needle-nose pliers
- Painter's tape (or similar)
- Paper towels
- Phillips screwdriver
- Plastic squeegee (or similar)

- Tap handle
- Two-by-four, two (or similar 3-in. block of wood)
- Wire crimper
- Wire stripper

1.4 BEFORE YOU BEGIN

- Automatic Oiler Required You must confirm that the mill is regularly oiled. If you don't, there's a risk of motor faults. Use an <u>Automatic Oiler Kit: 115 Vac (PN</u> <u>38254)</u>.
- ECMv1.5 Update Kit Required You must first install the ECM1v1.5 Update Kit (PN 39257). For information, see the product's documentation.
- Keep All Hardware To install the servo motors, you'll reuse many items currently used on the machine. Keep all hardware unless you're specifically instructed to discard it. If you don't, there's a risk that you won't have the hardware you need to complete the installation.
- PathPilot v2.2.1 or Later Required Only PathPilot v2.2.1 and later has settings required to use an M+ mill configuration. For information, go to "Update PathPilot" (page 4).

2.1 UPDATE PATHPILOT

Before you begin to install the 770M+ Servo Upgrade Kit, you must verify that the PathPilot controller is updated to the latest version of PathPilot. This is because only PathPilot v2.2.1 and later has settings required to use an M+ mill configuration.

To update PathPilot, do one of the following:

- "Download and Install an Update File" (below)
- "Install an Update File from a USB Drive" (below)
- 2.1.1 Download and Install an Update File

Note: Downloading and installing an update file requires an Internet connection. From the PathPilot interface, confirm that the Internet button LED light is on.

- Confirm that the PathPilot controller is powered on and out of **Reset** mode.
- From the PathPilot interface, on the Status tab, select Update.



Figure 2-1: Update button on the Status tab.

3. From the Software Update dialog box, select Check Online.



Figure 2-2: Software Update dialog box.





Figure 2-3: Install button on the Software Update dialog box.

The update file is downloaded, and a notification dialog box displays.

5. From the dialog box, select OK.

	Software Update	X
Check online for latest upd	lates	Check Online
PathPliot v2.0.4 - Fixed at Tool Changer (ATC) USB	dditional issues in relation to the new PCNC 440 Automatic interface chip.	Intal
	\mathbf{X}	
2 Check online da	Update downloaded successfully. Click OK to install.	
Update using file on	ОК	Bronte
		Close

Figure 2-4: OK button on the dialog box.

The update file is installed on the PathPilot controller.

- 6. Follow the on-screen instructions to restart the PathPilot controller.
- 2.1.2 Install an Update File from a USB Drive
 - 1. From <u>tormach.com/pp-updates</u>, download the most recent PathPilot update file.
 - 2. Transfer the PathPilot update file to a USB drive.
 - 3. Put the USB drive into the PathPilot controller.
 - 4. Confirm that the PathPilot controller is powered on and out of **Reset** mode.

 From the PathPilot interface, on the Status tab, select Update.



Figure 2-5: Update button on the Status tab.

6. From the Software Update dialog box, select Browse.



Figure 2-6: Software Update dialog box.

7. From the Browse dialog box, select USB.



Figure 2-7: Browse dialog box.

8. Select the desired update file, and then select Update.



Figure 2-8: Update button.

The update file is installed on the PathPilot controller.

9. Follow the on-screen instructions to restart the PathPilot controller.

3.1 REMOVAL

Complete the following steps in the order listed:

- **Step 1:** "Prepare the Machine" (below)
- Step 2: "Remove the Stepper Motor Drivers" (page 8)
- **Step 3:** "Remove the Stepper Motors" (page 10)
- 3.1.1 Prepare the Machine
 - 1. If you have any tooling in the spindle, remove it.
 - Loosen the four screws securing the drip guard to the front of the machine table with a 4 mm hex wrench. Then, remove the drip guard and set it aside.



Figure 3-1: Four screws and the drip guard.

 Remove the tool tray from the machine table with a 4 mm hex wrench. Set aside the screws and the tool tray.



Figure 3-2: Two screws and the tool tray.

4. Identify the X-axis motor below the left side of the machine table.



Figure 3-3: X-axis motor.

5. Identify the Y-axis motor on the rear of the machine.



Figure 3-4: Y-axis motor.

 Remove the motor mount cover from the X- and Y-axis motor with a 3 mm hex wrench. Set aside the screws and the motor mount cover.



Figure 3-5: X-axis motor mount cover.

 Identify the four set screws on both motor couplers, and examine the direction to which they point. To easily access the set screws, they must point toward you.



Figure 3-6: X-axis motor coupler set screws.

- Depending on the direction in which the set screws are pointing, do one of the following:
 - Set Screws Pointing Toward You Go to Step 9.
 - Set Screws Pointing Away from You This indicates that the machine table is positioned incorrectly. Move the machine table until the set screws on both the X- and Y-axis motor coupler are pointing toward you.
 - WARNING! Crash Hazard: You must support the spindle head as described in this document before you make any mechanical or electrical adjustments to the spindle head. (For example, loosening the set screws on the Z-axis motor coupler.) If you make adjustments without first supporting the spindle head, it could result in the spindle head crashing on the machine table.

- To prevent the spindle head from dropping onto the machine table, put a set of two-by-fours (or similar 3in. block of wood) on the machine table so that it's:
 - Below the spindle flange
 - Clear of the (optional) coolant nozzles



Figure 3-7: A set of two-by-fours on the machine table.

 Slowly jog the Z-axis down (-Z) until the spindle flange is on the set of two-by-fours.



Figure 3-8: Spindle flange on the set of two-by-fours.

NOTICE! Don't put the spindle nose on the set of two-by-fours. If you do, it could add unnecessary force to the spindle bearings, and damage the machine components.

 Identify the Z-axis motor mount cover plate below the Z-axis motor on the machine column.



Figure 3-9: Motor mount cover.

- Remove the motor cover from the machine column with a 3 mm hex wrench. Set aside the screws and the motor cover.
- 13. Identify the four set screws on the Z-axis motor coupler inside the Z-axis motor mount, and examine the direction to which they point. To easily access the set screws, they must point toward the left side of the machine once the Z-axis is lowered.



Figure 3-10: Set screws on the Z-axis coupler pointing toward the left side of the machine.

- 14. Depending on the direction in which the set screws are pointing, do one of the following:
 - Set Screws Pointing Left Go to Step 15.
 - Set Screws Not Pointing Left This indicates that the set of two-by-fours is too short for your machine. Repeat Steps 9 through 14 with a different block of wood.
 - WARNING! Electrical Shock Hazard: You must power off the machine before making any electrical connections. If you don't, there's a risk of electrocution or shock.
- 15. Power off the machine and the PathPilot controller.
 - Push in the Emergency Stop button on the operator box, which disables movement of the axes and the spindle.
 - b. From the PathPilot interface, select Exit.
 - c. Turn the Main Disconnect switch to **OFF** on the side of the electrical cabinet.
 - Remove the power plug(s) from the wall outlet. If your system is hardwired, isolate the machine by opening its circuit breaker(s).
 - e. Follow correct lockout/tagout procedures.
- 3.1.2 Remove the Stepper Motor Drivers

NOTICE! Only remove wires as instructed in this procedure. If you don't, there's a risk that you could remove wires required for future accessories (like a 4th axis).

1. Open the electrical cabinet door.

Note: Depending on the location of your machine and the amount of space you have to work in, you may it easier to first remove the electrical cabinet door and the ground screw.

2. From inside the electrical cabinet, remove the wire troughs as shown in the following image.



Figure 3-11: Wire troughs removed from the electrical cabinet.

3. Identify the stepper motor drivers.



Figure 3-12: Stepper motor drivers in the electrical cabinet.

4. Remove the green connectors and the ribbon cable connectors from the X, Y, and Z stepper motor drivers.



Figure 3-13: All connections removed from the stepper motor drivers.

Note: If you have an (optional) 4th axis, don'tremove any wires from its driver (in the electrical cabinet, it's furthest to the right).

- Remove the X, Y, and Z stepper motor drivers with a Phillips head screwdriver. Discard all three drivers and their six screws.
- Find the three ribbon cables that you removed in Step
 and then put them into the wire trough.
- Find the three green connectors that you disconnected in Step 4, and then remove all of the wires from each connector with a small, flat-blade screwdriver. Discard all three connectors.
- 8. Identify the DC-BUS board.



Figure 3-14: DC-BUS board in the electrical cabinet.

9. Remove wires 210, 211, 220, 221, 230, and 231 from the DC-BUS board with a needle-nose pliers.

Note: Pull the blue spade connector, not the wire itself.

- 10. Remove all of the stepper motors' wires from the wire troughs. There are 15 in total:
 - 210 through 214
 - 220 through 224
 - 230 through 234
- 11. Wires 210, 211, 220, 221, 230, and 231 are now completely disconnected from the electrical cabinet; discard them.
- 12. Identify the Z-axis brake wires: follow wire 400 and wire 435 (both black) from the Z-axis brake into the electrical cabinet.
- 13. When you install the new Z-axis brake that's provided with this kit, you must make its wire connections in place of the original Z-axis brake wires. Make note of the current location for both wire 400 and wire 435 in the electrical cabinet.
- 14. Remove wire 400 and wire 435 from the electrical cabinet with a small, flat-blade screwdriver. Then, remove both wires from the wire troughs.
- Remove the Z column panel with a 3 mm hex wrench. Set aside the screws and the column panel.
- Carefully move the following wires out of the electrical cabinet and through the Z column opening:
 - 212 through 214
 - 222 through 224
 - 232 through 234
 - 400
 - 435
- 17. Remove the sleeves from each of the three groups of wires, and set them aside.
- 3.1.3 Remove the Stepper Motors

Remove the X-Axis Stepper Motor

 On the motor coupler, loosen the two set screws that are closest to the motor with a 3 mm hex wrench.



Figure 3-15: Coupler set screws.

Note: If you loosen all four set screws at the same time, the coupler could disconnect from the ball screw shaft.

- On the machine column, remove the protective cover over the X-axis motor's flex conduit. Discard the protective cover and its screws.
- On the motor, identify the flex conduit. Then, follow it to the machine column, and remove its four screws from the machine column with a hex wrench. Set aside the screws.
- Pull the wires from the motor out of the machine column.
- Remove the plate (by the flex conduit fitting's hole) from the machine column with a a hex wrench. Set aside the plate and its screws.
- 6. Remove the motor from the machine with a 4 mm hex wrench.
- 7. Remove the flex conduit from the X-axis motor, and then pull the wires through the flex conduit.



Figure 3-16: Removing the flex conduit from the X-axis motor.

 Set aside the mounting screws, washers, and flex conduit for the installation of the servo motors. Then, discard the motor and its wiring.

> Note: Separate the X-axis flex conduit from the other motors' flex conduits. It's easy to confuse them, and you only need the X-axis' flex conduit for the installation of the servo motors.

Remove the Z-Axis Stepper Motor

WARNING! Crash Hazard: You must support the spindle head as described in this document before you make any mechanical or electrical adjustments to the spindle head. (For example, loosening the set screws on the Z-axis motor coupler.) If you make adjustments without first supporting the spindle head, it could result in the spindle head crashing on the machine table.

- To relieve tension from the ballscrew, loosen the two bottom set screws on the motor coupler with a 3 mm hex wrench, and then re-tighten them.
- 2. On the motor coupler, loosen the two top set screws with a 3 mm hex wrench.



Figure 3-17: Coupler set screws.

Note: If you loosen all four set screws at the same time, the coupler could disconnect from the ball screw shaft.

- 3. On the motor, identify the flex conduits. Then, follow them to the machine column, and remove them from the machine column with Channellock pliers.
- Pull the wires from the motor out of the machine column.
- 5. Remove the flex conduit fittings from the machine column with Channellock pliers. Discard the fittings.
- 6. Remove the motor from the machine with a 4 mm hex wrench.
- Set aside the mounting screws and washers for the installation of the servo motors. Then, discard the motor and its wiring.

Remove the Y-Axis Stepper Motor

 On the motor coupler, loosen the two set screws that are closest to the motor with a 3 mm hex wrench.





Note: If you loosen all four set screws at the same time, the coupler could disconnect from the ball screw shaft.

- On the motor, identify the flex conduit. Then, follow it to the machine column, and remove its four screws from the machine column with a hex wrench. Set aside the screws.
- Pull the wires from the motor out of the machine column.
- Remove the plate (by the flex conduit fitting's hole) from the machine column with a hex wrench. Set aside the screws.
- 5. Remove the motor from the machine with a 4 mm hex wrench.

6. Set aside the mounting screws and washers for the installation of the servo motors. Then, discard the motor and its wiring.

4.1 INSTALLATION

Complete the following steps in the order listed:

- Step 1: "Prepare the Machine for the X-Axis Motor Cover" (below)
- **Step 2:** "Install the Servo Motors" (below)
- * Step 3: "Make Electrical Connections" (page 18)
- **x** Step 4: "Verify the Installation" (page 19)
- **x** Step 5: "Apply the 770M+ Decals" (page 20)

4.1.1 Prepare the Machine for the X-Axis Motor Cover

On the X-axis motor mount, you must drill and tap four holes that you'll use to secure the X-axis motor cover. Use the template (provided in this document) to drill and tap the holes in the correct location.

To prepare the machine for the X-axis motor cover:

- 1. Find the X-axis motor cover provided.
- 2. Remove the six screws securing the plate to the motor cover with a 3 mm hex wrench, and set all aside.
- 3. Find the X-axis motor mount template provided.
- Align the template on the motor mount as shown in the following image. Then, use painter's tape to secure the template to the motor mount.



Figure 4-1: Template aligned on the motor mount.

5. Repeat Step 4 to secure the second template to the back of the motor mount.

6. To confirm that the template is correctly positioned, temporarily align the X-axis motor cover on the motor mount. The X-axis motor cover must be against the machine table (as shown in the image), and the surface between the motor mount and the X-axis motor cover must be flush.



Figure 4-2: X-axis motor cover aligned with the motor mount.

- 7. Set aside the X-axis motor cover.
- 8. Put a mark in each of the template's four holes on the motor mount with a center punch.



Figure 4-3: Center punch aligned on the front template.

- 9. Remove the templates from the motor mount.
- Drill each hole that you marked in Step 8 with the drill bit provided. Each hole should be approximately 3/4-in. deep.
- 11. Tap each hole that you drilled in Step 10 with the tap provided.

4.1.2 Install the Servo Motors

Install the X-Axis Servo Motor

 Find two flex conduit fittings and two adapter plates provided with this kit.

- Install two adapter plates (provided) in place of the quick-connect fittings (on the machine column) with the screws that you set aside in "Remove the Stepper Motors" (page 10).
- 3. Install the flex conduit fittings on to the adapter plate.
- 4. Find the X-Axis Servo Motor (PN 38406). Then, install it in place of the motor that you removed in "Remove the Stepper Motors" (page 10) with the screws and washers that you set aside. Verify that the motor is oriented so that the plug end is toward the front of the machine, as shown in the following image.



Figure 4-4: X-axis servo motor installed.

Note: If the motor isn't installed with the plug end toward the front of the machine, there could be interference between the motor's wires and the motor's cover.

- 5. Tighten the two set screws on the coupler closest to the motor with a 4 mm hex wrench.
- Put back the X-axis motor mount cover with the screws that you set aside in "Remove the Stepper Motors" (page 10).

 Install the X-axis motor cover to the motor mount using the four screws provided and a 4 mm hex wrench.



Figure 4-5: X-axis motor cover installed.

- You'll use two flex conduits to install the X-axis motor: one that you set aside in "Remove the Stepper Motors" (page 10), and one that you must assemble. To assemble the flex conduit:
 - Find the flex conduit and two flex conduit fittings provided with this kit.
 - Put one flex conduit fitting on either end of the flex conduit as shown in the following image.



Figure 4-6: Flex conduit fitting assembly.

9. Connect one end of each flex conduit to the motor cover.



Figure 4-7: Flex conduits connected to the motor cover.

 Find the servo power wires labeled 210 and 211 and the servo control wire labeled 424.

Tip! It may help to tape the ends of the
 cables together with electrical tape (or similar) before putting them through the flex conduit.

 Route the wires through each flex conduit fitting on the motor cover. Verify that the Molex connectors are on the servo side of the flex conduit fittings.



Figure 4-8: Routing the wires through the flex conduits.

- Move the wires through the flex conduit fitting on the machine column and into the rear access compartment.
- Tighten both flex conduits to their fittings on the machine column with Channellock pliers.

14. Find the dielectric grease provided with this kit. Then, put it on the Molex connectors of the servo power and control wires as shown in the following image.



Figure 4-9: Dielectric grease on the Molex connector.

15. Make the servo wire connections at the motor as shown in the following image.



Figure 4-10: Wire connections on the X-axis motor.

16. Put back the X-axis motor cover's plate with the six screws that you set aside in "Prepare the Machine for the X-Axis Motor Cover" (page 13).

17. Find the three plastic plugs provided in this kit, and put them on the motor cover as shown in the following images.



Figure 4-11: Plugs on the back of the motor cover.



Figure 4-12: Plugs on the left side of the motor cover.

Note: There may be extra plastic plugs provided with your kit.

- 18. To prevent coolant from entering the X-axis motor cover, you must first put on a layer of butyl tape before putting back the tool tray. Clean the surfaces of the Xaxis motor cover and the tool tray with a mild degreaser (like Simple Green®) to make sure that the butyl tape bonds.
- Find the roll of butyl tape provided, and the tool tray that you set aside in "Prepare the Machine" (page 6).

20. Remove the cover paper, and then put strips of butyl tape along the top edges of the X-axis motor cover as shown in the following image.



Figure 4-13: Butyl tape on the X-axis motor cover.

- 21. Remove the remaining cover paper from the butyl tape strips.
- 22. Cut two small pieces of butyl tape, as shown in the following image. Then, remove the cover paper, and put them on the bottom of the tool tray so that they're aligned with the screw holes.



Figure 4-14: Butyl tape on the X-axis motor mount's screw holes.

- 23. Remove the remaining cover paper from the butyl tape strips.
- Attach the tool tray to the X-axis motor mount with the screws that you set aside in "Prepare the Machine" (page 6).

- 25. Verify that the tool tray is flush with the machine table: move a 1-2-3 block (or similar) across the two surfaces. Depending on the result, do one of the following:
 - Tool Tray is Flush with the Machine Table Go to Step 26.
 - Tool Tray isn't Flush with the Machine Table Squeeze the tool tray down with a bar clamp until it's flush with the machine table, as shown in the following image. Then, tighten the screws.



Figure 4-15: Clamping the tool tray to the X-axis motor cover.

26. Find the two wires that you put into the machine column in the rear access compartment of the machine. Then, put the sleeves that you set aside in "Remove the Stepper Motor Drivers" (page 8) over them, and put the wires into the electrical cabinet.

Install the Z-Axis Servo Motor

- 1. Find two cable glands provided with this kit.
- 2. Install the two cable glands as shown in the following image.



Figure 4-16: Cable glands installed.

- Find the Z-axis brake. Then, install it on the machine column with the screws and washers that you set aside in "Remove the Stepper Motors" (page 10).
- 4. Put the Z-axis brake's wires through one of the cable glands on the machine column.
- So that you can access it, align the Z-axis brake's coupler and the hole on the brake with a 4 mm hex wrench.



Figure 4-17: Z-axis brake coupler aligned with the hole on the back of the brake.

- Find the Z-Axis Servo Motor (PN 38407). Then, install it in place of the motor that you removed in "Remove the Stepper Motors" (page 10) with four M5 flat washers, M5 lock washers, and M5 × 0.8 - 20 mm screws (provided in this kit).
- 7. Tighten the Z-axis brake coupler with a 4 mm hex wrench.
- On the Z-axis motor coupler, tighten the two set screws closest to the motor with a 4 mm hex wrench.
- 9. Find the servo power wires labeled 230 and 231 and the servo control wire with label 426.
- 10. Put one wire through each of the cable glands. Verify that the Molex connectors are on the servo side of the cable glands.

Tip! It may help to tape the ends of the cables together with electrical tape (or

- similar) before putting them through the flex conduit.
- 11. Tighten the cable glands around the wires with Channellock pliers.

- 12. Find the servo power wires, servo control wires, and Z-axis brake wires that you put into the machine column in the rear access compartment of the machine. Then, put the sleeves that you set aside in "Remove the Stepper Motor Drivers" (page 8) over them, and put the wires into the electrical cabinet.
- Put back the Z-axis motor mount cover plate with the screws that you set aside in "Prepare the Machine" (page 6).

Install the Y-Axis Servo Motor

- Find the Y-Axis Servo Motor (PN 38702). Then, install it in place of the motor that you removed in "Remove the Stepper Motors" (page 10) with the screws and washers that you set aside.
- 2. Tighten the two set screws on the coupler closest to the motor with a 4 mm hex wrench.
- Put back the Y-axis motor mount cover with the screws that you set aside in "Prepare the Machine" (page 6).
- 4. Find two cable glands and two adapter plates provided with this kit.
- Install two adapter plates (provided) in place of the quick-connect fittings (on the machine column) with the screws that you set aside in "Remove the Stepper Motors" (page 10).
- 6. Install the cable glands on to the adapter plates.
- Find the servo power wires labeled 220 and 221 and the servo control wire labeled 425.
- Put one wire through each of the cable glands. Verify that the Molex connectors are on the servo side of the cable glands.

Tip! It may help to tape the ends of the cables together with electrical tape (or similar) before putting them through the flex conduit.

- 9. Tighten the cable glands around the wires with Channellock pliers.
- Find the two wires that you put into the machine column in the rear access compartment of the machine. Then, put the sleeves that you set aside in "Remove the Stepper Motor Drivers" (page 8) over them, and put the wires into the electrical cabinet.

4.1.3 Make Electrical Connections

- Remove the four Phillips head screws securing the protective cover to the machine control board with a Phillips screwdriver. Then, set aside the screws and the cover.
- 2. Find the three green connectors provided with this kit.
- Identify the pin connection locations on the green connectors. Pin 1 is closest to the small triangle on the outside edge of the connector, as shown in the following image. Pins 2 through 8 follow in sequential order.



Figure 4-18: Triangle on the green connector, which indicates the location of pin 1.

- Find the three servo control wires that you put into the electrical cabinet in "Install the Servo Motors" (page 13).
- Connect each control wire to one of the connectors as detailed in the following table.

Wire Color	Pin Connection
Green	1
Black	2
White	3
Blue	4
Red	5
Yellow	6
Brown	7
Orange	8

6. Route the control wires through the wire troughs and toward the machine control board.

 Connect the connectors on the control wires to the machine control board as detailed in the following table.

Wire Number	Connection
424	J13
425	J14
426	J15

Note: The connection numbers are printed on the machine control board.

 Connect the Z-axis brake wires in place of the original Z-axis brake wires.

> Note: You noted the locations of the original Z-axis brake wires in "Remove the Stepper Motor Drivers" (page 8).

- Find the three servo power wires that you put into the electrical cabinet in "Install the Servo Motors" (page 13). Then, find the six spade electrical connectors provided in this kit.
- Remove 1/4 in. of insulation from each of the power cable wires. Then, crimp one spade electrical connector to each of the wires with a wire crimper.
- 11. Route the power wires through the wire troughs and toward the DC-BUS board.
- 12. Connect the spade connectors on the power wires to the DC-BUS board as detailed in the following table.

Wire Number	Connection
210	X-
211	Х+
220	Y-
221	Y+
230	Z-
231	Z+

- 13. Organize the wires into the wire troughs, and then put any excess wire into the machine column.
- 14. Put back the wire trough covers.

- 15. Put the protective cover back on the machine control board using the screws that you set aside earlier.
- 16. Close the electrical cabinet door.

4.1.4 Verify the Installation

- Put back the Z column cover that you set aside in "Prepare the Machine" (page 6).
- 2. Power on the machine and the PathPilot controller.
 - a. Insert the power plug(s) into the wall outlet. If your system is hardwired, restore power to the circuit breaker(s).
 - b. Turn the PathPilot controller strip to ON.
 - c. Turn the Main Disconnect switch to **ON** on the side of the electrical cabinet.
 - Twist out the Emergency Stop button on the operator box, which enables movement to the machine axes and the spindle.
 - e. Press the Reset button on the operator box.
 - f. Bring the machine out of reset and reference it.
- If you haven't yet done so, configure the PathPilot operating system for an M+ mill:
 - a. From the Main tab, in the MDI Line DRO field, type ADMIN CONFIG. Then select the Enter key.
 - b. From the Tormach Machine Controller Configuration screen, select the new machine configuration. Then select Save and Exit. The PathPilot interface displays.
- 4. From the PathPilot interface, select Reset.
- Confirm that the machine can freely move to the reference position:
 - To make sure that the spindle is clear of any possible obstructions, reference the Z-axis before referencing the other axes: from the PathPilot interface, select Ref Z.
 - b. Once the spindle is clear of any possible obstructions, select **Ref X** and **Ref Y**.

- Depending on the result of Step 5, do one of the following:
 - Correct Movement Remove the set of two-byfours on the machine table, and put back the drip tray that you set aside in "Prepare the Machine" (page 6).
 - Incorrect Movement We can help. Email <u>support@tormach.com</u> to contact Tormach Technical Support for guidance on how to proceed.

4.1.5 Apply the 770M+ Decals

We recommend using a wet application procedure to put the decals on your machine. It's easier to do (you can adjust as you work) and it creates a more professional appearance (you can easily push out air bubbles) – but it takes time to dry. Wait to use the machine until the decals dry completely so that you don't risk swarf (or other debris) moving the decals out of position.

To apply the 770M+ decals:

- Remove the original 770M decals on your machine. There's one on the front of the electrical cabinet, and one on the front left panel of the enclosure.
- 2. Find the enclosure and electrical cabinet decals provided with this kit.
- 3. Clean the surface of the removed decals with Simple Green (or similar). Then, let the surface dry.
- 4. Identify the location for the new electrical cabinet decal: measure 5.5 in. from the bottom of the electrical cabinet, and make a mark. This indicates the correct location for the bottom of the new electrical cabinet decal. Repeat this step several times to help you align the new decal.



Figure 4-19: Marking the electrical cabinet for the new decal.

- Identify the location for the new enclosure decal: measure 3.86 in. from both sides of the electrical cabinet, and make a mark on either side. This indicates the correct location for the sides of the new enclosure decal. Repeat this step several times to help you align the new decal.
- 6. Spray the application area with an ammonia-free window cleaner (or similar). The amount of window cleaner that you use determines how much flexibility you'll have to position the decal. If you use more window cleaner, it'll take longer to dry.

Note: You must use ammonia-free window cleaner to prevent air bubbles from forming.

- 7. Remove the protective backing from the decal.
- Position the decals on the marks that you made in Step 4 and Step 5.



Figure 4-20: Positioning the new decal on the electrical cabinet.

9. Push out all the air bubbles with a plastic squeegee (or similar).



Figure 4-21: Pushing out air bubbles on the new decal.

- 10. Carefully wipe the excess window cleaner off of the decal.
- 11. Allow up to a day for the decal to dry completely.

Note: Wait to use the machine until the decals dry completely so that you don't risk swarf (or other debris) moving the decals out of position.

12. Carefully remove the transfer paper from the decal.

This page intentionally left blank.

770M X-AXIS MOTOR MOUNT TEMPLATE

Cut each template along the lines. Then, tape the templates to the X-axis motor mount (in the orientation indicated on the templates themselves).

For information on drilling and tapping the holes, see the Servo Upgrade Kit documentation.

KEY



Measure the square (above) to confirm that this drawing is printed to scale. If the square is not accurate in both X and Y, reprint this drawing on a 1:1 scale.



